



Advance Bark Control



DMT Advance Bark Control Collar

Manual

Australia:

Address: Unit2/6 Nuban Street, Currumbin Waters, QLD 4223

Phone: 07 5559 9100 / Web: www.dogmaster.com.au

New Zealand:

Address: P.O. Box 12741, Chartwell, Hamilton 3210


Phone: (07) 855 4799 / Web: www.dogmaster.co.nz



**Z1076
N13047**

Main Features:

- 7 levels of stimulation
- 5 sensitivity settings for different dog's temperament
- Small and lightweight collar
- Water resistant collar, operated by 6V alkaline battery
- LED indicator for battery and operation



ON-OFF & Intensity Dial

The ON-OFF & Intensity Dial on the collar is used to turn the DMT Advance Bark Collar on and off to select the intensity level.

Set the ON-OFF & Intensity Dial to the "OFF" position to turn off the DMT Advance Bark Collar.



Level 1 is the lowest level of stimulation and Level 7 is the highest.

The DMT Advance bark collar has a built in safety feature which will automatically shut off for 1 minute if it is activated 5 times or more. The LED light will flash Red and Green during this period of time. Then the light will be off to indicate it is back to sleep mode.

Sensitivity Dial

The sensitivity dial is used to adjust the sensitivity level of the vibration sensor. Level 5 is the highest sensitive level and level 1 is the lowest. This means the collar is easy to activate in level 5 and then less chance to activate at level 1.



Installing the Battery


- 1) Use a 10 cent coin to open the battery screw cap.
- 2) Insert the 6V alkaline battery into the battery tray with the negative (-) facing inside (SEE DIAGRAM)
- 3) Use the 10 cent coin to screw the battery cap back onto the collar



Please note: If the LED indicator flashes Red when the collar is turned on, it means the battery needs to be replaced.

Testing

1. Turn the “Intensity” level to 1 and the “Sensitivity Dial” to level 5
2. Test by scratching the rough surface of the test tool on the collar (as shown in the diagram) using a coin or a pen. The LED light should flash Green to indicate the collar is working.



Fitting the Collar

The collar strap should be adjusted so that the contact points are held firmly against the dog's skin. Fasten the collar enough to allow one or two fingers to fit between the collar strap and your dog's neck.

If the collar is too loose, it will be ineffective because there is no contact between the dogs' skin and the contact points.

Collar should not be used for more than 10 hours per day. If a rash develops, discontinue use.

Regular Maintenance

- Check Contact Points for tightness weekly, do not over tighten.
- Clean Contact Points with alcohol/metho weekly
- Replace Battery when it is required

(Note: make sure the collar is turned off for checking and cleaning.)

- Check your dog's neck for irritation and wash neck weekly.

12 Months Warranty:

All of our products are covered by warranty. Our warranty offers free repair for manufacturing faults. It does not cover damage as a result of inappropriate use of the product, wear and tear, damage from impact, dog chews, over-use or abuse or the depletion of consumables, such as batteries or citronella spray etc. The warranty is also not applicable if the product is used in ways that are outside the products intended use.

Australia Only:

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure."